ITEM NO.	PART NO.	QTY.	DESCRIPTION	PACKED BY
1	TS1081	1	SEAT SWIVEL ASSEMBLY	
2	10X25MBSS	4	M10 x 25mm BUTTON HEAD SET SCREW	
3	10MSW	4	M10 SPRING WASHER	
4	10MZPW	4	M10 FLAT WASHER	
5	10MNYLN	4	M10 NYLOC NUT	
6	TS-LB07	1	SWIVEL WARNING STICKER	
7	47	1	650X500X600 SCORED CARTON	
8	KF002	4	S CLASS 0.500 X 0.26 X 0.060	
9	KF003	1	1.225 X 0.26 X 0.015	

Ø

ORIGINAL SEAT

ASSEMBLY INSTRUCTIONS

1. REMOVE ORIGINAL SEAT

- 2. TURN THE SEAT SWIVEL TO APPROX. 30° TO ALLOW ACCESS TO THE BOLT HOLES
- 3. FIT THE SEAT TO THE TOP PLATE OF THE SWIVEL USING THE SUPPLIED M10 x 25mm BOLTS (2), WASHERS (3, 4) AND NYLOC NUTS (5)
- 4. FIT THE BOTTOM PLATE OF THE SWIVEL TO THE ORIGINAL SEAT FRAME USING THE ORIGINAL SEAT BOLTS (6)
- 5. TEST SWIVEL OPERATION (REFER IMPORTANT NOTE BELOW)

2

3

5

NOTE: TORQUE M10 BOLTS TO 44Nm

OEM SEAT BOLT

OEM SEAT BELT

1

2

The installer must label the seat with this Warning: THIS SEAT IS ONLY TO **BE USED IN THE FORWARD FACING POSITION WHEN THE VEHICLE IS IN** MOTION

The handbrake mount will require an offset modification to allow the installation of the Drivers side seat swivel. This modification must be made by the installer or vehicle body builder.

This swivel cannot be fitted if OEM seats are suspension or non-factory type.

Ø

Ø

Important: Swivel must be tested before job is complete. If the swivel is tight or hard to turn, scan the QR code to the right to see a troubleshooting guide.

PROPRIETARY AND CONFIDENTIAL

2

2

3

5

3

5

Aftermarket seats and swivels sold by Techsafe Seating have been tested by an approved testing authority in Australia and found to meet the strength and performance requirements of the appropriate standards Aftermarket seats and swivels should only be installed by competent and experienced personnel Aftermarket seats and swivels in some state jurisdictions may require certification by a qualified certifying engineer. In all instances professional engineering advice should be sought to ensure the suitability of the integration of the seat or ivel into the original vehicle structure and to consider for any effect the modification may have on that vehicles compliance with legislated standards.

IMPORTANT INFORMATION FOR INSTALLERS

As the manufacturer and seller of this product has no control over the end use or the fitment to the vehicle, the manufacturer and seller accepts no responsibility or liability for any malfunction of the product or the vehicle occupant safety systems as a direct or indirect result of faulty installation or unauthorized repair or modification to this product.

Ø

 \bigcirc

Modification of the seat, swivel or installation kit should not be made without certification by a qualified engineer or manufacturers written consent.

Where components of the installation kit are modified to better suit the specific nature of the installation, these must be substituted with components of equivalent or greater strength. Good engineering practice should be evident at all times including the use of metal spacers between brackets and the floor pan, appropriately torqued anchorage bolts, rust prohibitors on drilled holes and adhesive sealant used on underfloor backing plates.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TECHSAFE. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TECHSAFE IS PROHIBITED.



-**O**

WEIGHT

